




## SECURITY INSTRUCTIONS

All wiring should be done by a qualified electrician according to your regulation of your country. Before starting installation, make sure that the power is disconnected by turning off the circuit breakers to the outlet box and associated wall switch location.

1. If a LED doesn't light, don't repair by yourself. Contact a specialized service.
2. Do not connect if lamp is damaged (cracked, broken, etc).
3. The transformer included is specific to LED technology. In case of failure, to replace please consult a qualified electrician or your dealer for the appropriate replacement.
4. Do not use extension cords for the connection.
5. LED technology generates no significant heat forward, but backward. Observe the temperature dissipation (installation specifications).
6. Do not install close to fountains, pools, etc. Constant dripping water or water jets on the lamp may damage it.
7. SAVE THESE INSTRUCTIONS.




MODEL	CL218-29	100-240V~50/60Hz LED 11W 2700K 800Lm (INCL) DRIVER (INCL)			
					---0.5m



## SECURITY INSTRUCTIONS

All wiring should be done by a qualified electrician according to your regulation of your country. Before starting installation, make sure that the power is disconnected by turning off the circuit breakers to the outlet box and associated wall switch location.

1. If a LED doesn't light, don't repair by yourself. Contact a specialized service.
2. Do not connect if lamp is damaged (cracked, broken, etc).
3. The transformer included is specific to LED technology. In case of failure, to replace please consult a qualified electrician or your dealer for the appropriate replacement.
4. Do not use extension cords for the connection.
5. LED technology generates no significant heat forward, but backward. Observe the temperature dissipation (installation specifications).
6. Do not install close to fountains, pools, etc. Constant dripping water or water jets on the lamp may damage it.
7. SAVE THESE INSTRUCTIONS.




MODEL	CL218-35	100-240V~50/60Hz LED 15W 2700K 1200Lm (INCL) DRIVER (INCL)			
					---0.5m



## SECURITY INSTRUCTIONS

All wiring should be done by a qualified electrician according to your regulation of your country. Before starting installation, make sure that the power is disconnected by turning off the circuit breakers to the outlet box and associated wall switch location.

1. If a LED doesn't light, don't repair by yourself. Contact a specialized service.
2. Do not connect if lamp is damaged (cracked, broken, etc).
3. The transformer included is specific to LED technology. In case of failure, to replace please consult a qualified electrician or your dealer for the appropriate replacement.
4. Do not use extension cords for the connection.
5. LED technology generates no significant heat forward, but backward. Observe the temperature dissipation (installation specifications).
6. Do not install close to fountains, pools, etc. Constant dripping water or water jets on the lamp may damage it.
7. SAVE THESE INSTRUCTIONS.




MODEL	CL218-42	100-240V~50/60Hz LED 24W 2700K 1920Lm (INCL) DRIVER (INCL)
MODEL	CL218-51	100-240V~50/60Hz LED 32W 2700K 2560Lm (INCL) DRIVER (INCL)



## SECURITY INSTRUCTIONS

All wiring should be done by a qualified electrician according to your regulation of your country. Before starting installation, make sure that the power is disconnected by turning off the circuit breakers to the outlet box and associated wall switch location.

1. If a LED doesn't light, don't repair by yourself. Contact a specialized service.
2. Do not connect if lamp is damaged (cracked, broken, etc).
3. The transformer included is specific to LED technology. In case of failure, to replace please consult a qualified electrician or your dealer for the appropriate replacement.
4. Do not use extension cords for the connection.
5. LED technology generates no significant heat forward, but backward. Observe the temperature dissipation (installation specifications).
6. Do not install close to fountains, pools, etc. Constant dripping water or water jets on the lamp may damage it.
7. SAVE THESE INSTRUCTIONS.



MODEL	CL218-42	100-240V~50/60Hz LED 24W 2700K 1920Lm (INCL) DRIVER (INCL)
MODEL	CL218-51	100-240V~50/60Hz LED 32W 2700K 2560Lm (INCL) DRIVER (INCL)